



## Kick Guard Installation



### CONTENTS

- [1] 3M K500 (Adhesion promoter)
- [2] 3M PAC300 (Degreaser)
- [3] Masking tape (0.24inch×0.7inch)
- [4] Instruction [1](#) [2](#)
- [5] gloves

### CAUTION

Apply except for the part to be pasted please do not. **If you paste it on the internal plastic parts, it will turn white Or shine.** Work after fixing with attached masking tape absolutely .

**STEP 1:** Please be sure to remove dirt and oil inside the door using the 3M PAC300 Cleaner.



**STEP 2:** Align product with your door to note installation location and proper fit. (DO NOT REMOVE ADHESIVE BACKING YET)



**STEP 3:** Use provided masking tape to mask the outer perimeter of the mounting location. Apply 3M K500 Adhesion Promoter to mounting location paying extra attention to the outer edges.



**STEP 4:** Remove the adhesive backing on the inner portion of the kick guard and carefully place into the mounting location. Remove the backing from the outer edge and remove masking tape. Apply 3M K500 once again on the edges for extra hold.

