



OLM TR STYLE FRONT BUMPER SKIRT COVER

2017-2020 Toyota 86

1. Apply crosslinking agent before install the seal strip.



2. Peel paper backing from the seal strip.



- B. Attach strip (tooth side first) from inside out, as figure shows.



- C. Cut off the extra strips in the end.



*Adjust first section of strip if needed.



3. Screw the metal sheet with screw nuts on the back, as figures show. (Screw 4x10mm, nuts 4x8mm)



4. Make sure double side tape attached well and correctly between front lip and bumper.
5. Tighten four tapping screws under the front lip. (tapping screws: 1/4 x 5/8 TP 6x15 Washer: 6.3x13x1)



6. Insert U nut clip on the two sides of bumper as below figure shows. Screw tapping screws after the front lip and bumper are aligned. (Tapping screw: 5x16 TP2 Washer: 5.3x12x1)

