



OLM Signature Series E-Brake Handle

Part #: OLM.A.70217.1 – RD, BL, BK, CH

Application: 2015-2021 WRX & STi, 2013-2020 FR-S/BRZ/86, 2014-2018 Forester

Questions? Email us at: sales@subispeed.com

Parts List:

- ① - OLM Signature Series E-Brake handle w/ 3 included set screws



Tools Required:

5/64" allen key

Trim removal tool (optional)

Installation Instructions:

1 – Start by parking your car on a level surface, chock your wheels to prevent it from rolling forward or backward since you'll be doing work to your emergency brake handle

2 – Remove the e-brake boot and attached plastic by pinching the back of the e-brake boot between 2 fingers and pulling straight up, as shown below. This should partially pop the retainer and boot out.



3 – Next, put your hand between the lower seat cushion and the center console and find the bottom of the e-brake boot and plastic trim ring. Pull straight up to release the rest of the clips. The e-brake boot should now be free from the center console



4 – Next, grip your factory e-brake handle and push it out towards your radio, this may take some force but wiggling it back and forth while pulling forward should be all it takes



5 – Now with the handle and boot loose, remove them from the e-brake lever and remove the factory e-brake handle by sliding it out the bottom of the e-brake boot

6 – Next, place the boot back over the lever but do not snap it into place

7 – Loosen all 3 set screws on your new e-brake handle and slide the handle onto the e-brake lever until the bottom contacts the base of the lever, as shown below. Be sure to orient the handle the same way.



8 – Next, using a 5/64" allen key, tighten all 3 set screws until they are snug against the e-brake lever and the handle is no longer able to move

9 – Last, snap the plastic boot retainer back into your center console and tuck the boot back over your new handle, covering the set screws



10 – Check to make sure you e-brake and the releases button operate as they should. Your install is now complete