



### OLM JDM Style Canards

Part #: OLMA.70231: .1, .2, OLMA.70065.4: K7X, D4S, 61K, K1X, G1U, K3X, M7Y, E8H, C7P,  
OLMA.70044.1

Application: 2015-2021 WRX & STi

### General Note Regarding Automotive Adhesive

**Temperature:** Ideal application temperature range is 70°F to 100°F (21°C to 38°C). Pressure sensitive adhesives use viscous flow to achieve substrate contact area.

**Time:** After application, the bond strength will increase as the adhesive flows onto the surface (also referred to as “wet out”). At room temperature approximately 50% of ultimate bond strength will be achieved after 20 minutes, 90% after 24 hours and 100% after 72 hours. This flow is faster at higher temperatures and slower at lower temperatures.

### Parts List:

① - JDM Canard, Left (1)

② - JDM Canard, Right (1)



## Installation Instructions

1 – Thoroughly clean the area on your front bumper where you plan to apply the canards, taking care to remove any dirt, dust, or road debris and ensure the surface is dry and free of contaminants

2 – Cut and apply included adhesive in strips as shown in below



3 – Peel the backing off the adhesive and position the canard according to your front bumper type, as shown below in Figures 1 and 2.



**Figure 1: Suggested installation location:  
15-17 front bumper**



**Figure 2: Suggested installation location:  
18-21 front bumper**

4 – Once you have the canard positioned, press firmly for 30 seconds to ensure a good bond takes place

5 – Repeat steps 1-3 on the other side of your vehicle