

Opening WRX / STI headlights does not require "baking". Most people can separate the headlight lens from the housing at room temperature.

During this time you may want to upgrade to HID projectors and upgrade your side markers.

Download instructions [here](#).

NOTE: These LED boards **MUST** be connected to the LED drivers **FIRST** and then the LED drivers connect to the XBT controller.

XBT Controller instructions [here](#).